

## Importance of being a





- Communicate any above, below and around hazards to the Operator
- Make sure no one enters the danger zone

5

6

Stay at least 10 feet away from all sides of the machinery (back, front, left and right sides)

Maintain eye contact with the driver/operator, even if you must change positions frequently.

- Prevent damage to property
- Maintain radio contact (verbal contact) with driver









## Importance of being a

Communicate any above, 1 below and around hazards to the Operator

Make sure no one enters the danger zone

Stay at least 10 feet away from all sides of the machinery (back, front, left and right sides)

5

Maintain eye contact with the driver/operator, even if you must change positions frequently.

Prevent damage to property

6

Maintain radio contact (verbal contact) with driver

## **PPE Requirements**

Hard Hat

3

Safety Glasses



Hearing protection





Gloves



High vis vest



Steel toed boots











